'Click' to download complete Manual

Learning ◆ Knowledge ◆ Performance

D009/D011/D012/ D013/D091/D092 SERVICE MANUAL

003315MIU

LANIER RICOH savin

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

RICOH
Learning • Knowledge • Performance
UNIVERSITY

D009/D011/D012/
D013/D091/D092
SERVICE MANUAL

LANIER
RICOH
SAVIN

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

RICOH UNIVERSITY
Learning ◆ Knowledge ◆ Performance

service-repairmanual.com

D009/D011/D012/ D013/D091/D092 SERVICE MANUAL

003315MIU

LANIER RICOH SAVIN

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Americas Corporation and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH AMERICAS CORPORATION.

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.
They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

service-repairmanual.com

© 2010 RICOH Americas Corporation. All rights reserved.

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

WARNING

The Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Americas Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Americas Corporation

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

service-repairmanual.com

LEGEND

PRODUCT CODE	COMPANY			
	GESTETNER	LANIER	RICOH	SAVIN
D009	MP 4000B	LD040B	Aficio MP 4000B	9040b
D011	MP 4000	LD040	Aficio MP 4000	9040
D012	MP 5000B	LD050B	Aficio MP 5000B	9050b
D013	MP5000	LD050	Aficio MP 5000	9050
D091-17	MP 4001SP	LD140SP	Aficio MP 4001SP	9240SP
D092-17	MP 5001SP	LD150SP	Aficio MP 5001SP	9250SP
D091-57	MP 4001G	LD140G	Aficio MP 4001G	9240G
D092-57	MP 5001G	LD150G	Aficio MP 5001G	9250G

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
*	01/2010	Original Printing

CÓPIA NÃO CONTROLADA

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

D009/D011/D012/D013/D091/D092

TABLE OF CONTENTS

PRODUCT INFORMATION

1. PRODUCT INFORMATION.....1-1
1.1 SPECIFICATIONS 1-1
1.2 MACHINE CONFIGURATION 1-2
1.2.1 COPIER 1-2
1.3 GUIDANCE FOR THOSE WHO ARE FAMILIAR WITH PREDECESSOR PRODUCTS 1-5
1.4 OVERVIEW 1-6
1.4.1 COMPONENT LAYOUT 1-6
1.4.2 PAPER PATH 1-8
1.4.3 DRIVE LAYOUT 1-9

INSTALLATION

2. INSTALLATION 2-1
2.1 INSTALLATION REQUIREMENTS 2-1
2.1.1 ENVIRONMENT 2-2
2.1.2 MACHINE LEVEL 2-3
2.1.3 MINIMUM SPACE REQUIREMENTS 2-3
2.1.4 POWER REQUIREMENTS 2-4
2.2 INSTALLATION FLOW CHART 2-5
2.3 MAIN MACHINE INSTALLATION 2-6
2.3.1 ACCESSORY CHECK 2-6
2.3.2 INSTALLATION PROCEDURE 2-8
Preliminary Procedures 2-8
Fire Prevention Cover 2-10
PCDU (Photoconductor and Development Unit) 2-10
Toner Bottle 2-13
Paper Trays 2-14

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

Initialize TD Sensor and Developer 2-14
Set Paper Size for Paper Trays 2-15
Electrical Total Counter 2-15
Exposure Glass Cleaner 2-16
Operation Instructions Holder 2-16
Settings Relevant to the Service Contract 2-17
App 2 Me Setting (D091/D092 only) 2-17
2.3.3 MOVING THE MACHINE 2-19
2.3.4 TRANSPORTING THE MACHINE 2-19
2.4 PAPER FEED UNIT INSTALLATION (D351) 2-20
2.4.1 ACCESSORY CHECK 2-20
2.4.2 INSTALLATION PROCEDURE 2-20
2.5 LCT 2000-SHEET 2-24
2.5.1 ACCESSORY CHECK 2-24
2.5.2 INSTALLATION PROCEDURE 2-24
2.6 1200-SHEET LCT (D353) 2-27
2.6.1 COMPONENT CHECK 2-27
2.6.2 INSTALLATION PROCEDURE 2-28
2.7 AUTO REVERSE DOCUMENT FEEDER (B802) 2-30
2.7.1 COMPONENT CHECK 2-30
2.7.2 INSTALLATION PROCEDURE 2-31
2.8 PLATEN COVER INSTALLATION (G329) 2-35
2.9 1-BIN TRAY UNIT (D389) 2-36
2.9.1 COMPONENT CHECK 2-36
2.9.2 INSTALLATION PROCEDURE 2-36
2.10 BRIDGE UNIT (D386) 2-39
2.10.1 COMPONENT CHECK 2-39
2.10.2 INSTALLATION PROCEDURE 2-39
2.11 2000/3000-SHEET FINISHERS (B804/B805) 2-43
2.11.1 ACCESSORY CHECK 2-43
2.11.2 INSTALLATION PROCEDURE 2-44
Support Tray Installation 2-48
2.12 PUNCH UNIT 2-49
2.12.1 COMPONENT CHECK 2-49
2.12.2 INSTALLATION PROCEDURE 2-50
2.13 1000-SHEET FINISHER (B408) 2-54

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

2.13.1 ACCESSORY CHECK 2-54
2.13.2 INSTALLATION PROCEDURE 2-55
2.14 KEY COUNTER BRACKET 2-58
2.14.1 INSTALLATION PROCEDURE 2-58
2.15 KEY COUNTER INTERFACE UNIT 2-60
2.15.1 INSTALLATION PROCEDURE 2-60
2.16 ANTI-CONDENSATION HEATER (SCANNER) 2-62
2.16.1 INSTALLATION PROCEDURE 2-62
2.17 TRAY HEATER 2-64
2.17.1 INSTALLATION PROCEDURE 2-64
2.18 TRAY HEATER (OPTIONAL PAPER FEED UNIT) 2-66
2.18.1 COMPONENT CHECK 2-66
2.18.2 INSTALLATION PROCEDURE 2-67
For installing the tray heater in the D351 (Two-tray paper feed unit) .. 2-67
For installing the tray heater in the D352 (LCT) 2-70
2.19 HDD OPTION (D362, ONLY FOR D009/D012) 2-74
2.19.1 COMPONENT CHECK 2-74
2.19.2 INSTALLATION PROCEDURE 2-75
After Installing the HDD 2-76
2.20 COPY DATA SECURITY UNIT 2-77
2.20.1 INSTALLATION PROCEDURE 2-77
User Tool Setting 2-78
2.21 CONTROLLER OPTIONS 2-80
2.21.1 CONTROLLER BOARD SLOTS 2-80
SD Slot 1, Slot 2 2-80
Board Slot 2-81
2.21.2 IEEE1284 2-82
Installation Procedure 2-82
2.21.3 IEEE 802.11A/G, G (WIRELESS LAN) 2-82
Installation Procedure 2-82
UP Mode Settings for Wireless LAN 2-84
SP Mode Settings for IEEE 802.11a/g, g Wireless LAN 2-86
2.21.4 BLUETOOTH 2-87
2.21.5 GIGABIT ETHERNET 2-88
2.21.6 FILE FORMAT CONVERTER 2-89
2.21.7 POSTSCRIPT 3 2-90

service-manual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

2.21.8 IPDS UNIT 2-91
Accessories 2-91
Installation 2-91
2.21.9 HDD ENCRYPTION UNIT 2-93
Before You Begin the Procedure 2-93
Seal Check and Removal 2-94
Installation Procedure 2-94
Recovery from a Device Problem 2-96
2.21.10 DATAOVERWRITESECURITY UNIT TYPE I (D362) 2-98
Before You Begin the Procedure 2-98
Seal Check and Removal 2-99
Installation Procedure 2-100
2.21.11 BROWSER UNIT TYPE D 2-102
Installation Procedure 2-102
Update Procedure 2-104
2.21.12 VM CARD TYPE F (D377) 2-105
Accessories 2-105
Installation 2-106
2.21.13 PRINTER AND P/S OPTIONS (ONLY FOR D009/D012) 2-106
Overview 2-106
Kit Contents 2-108
Printer/Scanner Installation 2-110
Printer Enhance, Scanner Enhance Options 2-112
2.21.14 CHECK ALL CONNECTIONS 2-117

servicerepairmanual.com

PREVENTIVE MAINTENANCE

3. PREVENTIVE MAINTENANCE 3-1
3.1 PM TABLES 3-1

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

REPLACEMENT AND ADJUSTMENT

4. REPLACEMENT AND ADJUSTMENT 4-1

4.1 GENERAL CAUTIONS 4-1
4.1.1 LASER UNIT 4-1
4.1.2 USED TONER 4-1
4.2 SPECIAL TOOLS AND LUBRICANTS 4-2
4.2.1 SPECIAL TOOLS 4-2
4.2.2 LUBRICANTS 4-2
4.3 EXTERIOR COVERS 4-3
4.3.1 FRONT DOOR, UPPER AND LOWER INNER COVER 4-3
Upper Inner Cover 4-3
Lower Inner Cover 4-3
4.3.2 LEFT COVER 4-4
4.3.3 REAR COVER 4-4
4.3.4 RIGHT REAR COVER 4-5
4.3.5 OPERATION PANEL 4-6
4.3.6 PAPER EXIT COVER 4-7
4.3.7 INNER TRAY 4-8
4.4 SCANNER -1 4-9
4.4.1 EXPOSURE GLASS 4-9
4.4.2 ORIGINAL LENGTH/WIDTH SENSORS 4-10
Monochrome Scanner Model (D009/D012) 4-10
Color Scanner Model (D011/D013/D091/D092) 4-11
4.4.3 EXPOSURE LAMP 4-11
Color Scanner Model (D011/D013/D091/D092) 4-11
Monochrome Scanner Model (D009/D012) 4-13
4.4.4 SCANNER MOTOR 4-13
4.4.5 SENSOR BOARD UNIT (SBU) 4-14
Monochrome Scanner Model (D009/D012) 4-14
Color Scanner Model (D011/D013/D091/D092) 4-15
When reassembling 4-15
4.4.6 LAMP STABILIZER 4-16
4.4.7 SIO (SCANNER IN/OUT) BOARD 4-16

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

4.4.8 SCANNER HP SENSOR 4-17
4.4.9 PLATEN COVER SENSOR 4-18
4.5 SCANNER-2 4-19
4.5.1 FRONT SCANNER WIRE 4-19
Reassembling the Front Scanner Wire 4-19
4.5.2 REAR SCANNER WIRE 4-22
Reassembling the Rear Scanner Wire 4-23
4.5.3 TOUCH PANEL POSITION ADJUSTMENT 4-24
4.6 LASER UNIT 4-26
4.6.1 CAUTION DECAL LOCATIONS 4-26
4.6.2 LASER UNIT 4-26
4.6.3 POLYGON MIRROR MOTOR 4-28
4.6.4 LASER SYNCHRONIZATION DETECTOR 4-28
4.6.5 LD UNIT 4-29
Laser Beam Pitch Adjustment 4-29
4.7 PCDU 4-32
4.7.1 PCDU (PHOTOCONDUCTOR AND DEVELOPMENT UNIT) 4-32
Reinstallation 4-32
4.7.2 DRUM 4-33
Re-installation 4-35
4.7.3 PICK-OFF PAWLS 4-36
Pick-off Pawl Position Adjustment 4-36
4.7.4 CHARGE ROLLER AND CLEANING ROLLER 4-37
4.7.5 DRUM CLEANING BLADE 1 4-38
Re-installation 4-38
4.7.6 ID SENSOR 4-39
4.8 DEVELOPMENT 4-40
4.8.1 DEVELOPMENT FILTER 4-40
4.8.2 DEVELOPMENT ROLLER 4-41
Cleaning Procedure 4-41
4.8.3 DEVELOPER 4-43
4.8.4 TD SENSOR 4-45
4.9 TRANSFER 4-46
4.9.1 TRANSFER BELT UNIT 4-46
4.9.2 TRANSFER BELT 4-47
4.9.3 TONER OVERFLOW SENSOR 4-49

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

4.9.4 TRANSFER BELT CLEANING BLADE 4-49
4.10 PAPER FEED 4-50
4.10.1 PAPER FEED UNIT 4-50
Tray 1 and Tray 2 4-50
4.10.2 PICK-UP, FEED AND SEPARATION ROLLERS 4-51
Tray 1 and Tray 2 4-51
4.10.3 TRAY LIFT MOTOR 4-52
4.10.4 RELAY, TRAY LIFT, PAPER END AND PAPER FEED SENSORS 4-53
Tray 1 and Tray 2 4-53
4.10.5 REGISTRATION SENSOR 4-54
Reinstall the registration sensor 4-55
4.11 FUSING 4-56
4.11.1 FUSING UNIT 4-56
4.11.2 WEB ROLLER UNIT 4-57
4.11.3 BRAKE PAD 4-57
4.11.4 WEB HOLDER ROLLER AND WEB ROLLERS 4-58
Installing a new web holder roller 4-60
Installing new web rollers 4-60
4.11.5 PRESSURE ROLLER CLEANING ROLLER 4-61
4.11.6 THERMOSTAT 4-62
4.11.7 THERMISTOR 4-63
4.11.8 HOT ROLLER STRIPPERS 4-64
4.11.9 FUSING LAMPS 4-65
4.11.10 HOT ROLLER AND PRESSURE ROLLER 4-66
4.12 PAPER EXIT 4-67
4.12.1 PAPER EXIT UNIT 4-67
4.12.2 FUSING EXIT, PAPER OVERFLOW, AND PAPER EXIT SENSORS 4-67
Paper Exit Sensor 4-68
Paper Overflow Sensor 4-68
Fusing Exit Sensor 4-68
4.12.3 JUNCTION JAM SENSOR 4-68
4.12.4 PAPER EXIT MOTOR 4-69
4.13 DUPLEX 4-70
4.13.1 DUPLEX UNIT 4-70

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

4.13.2 RIGHT DOOR COVER 4-72
4.13.3 DUPLEX DOOR SENSOR 4-72
4.13.4 DUPLEX ENTRANCE SENSOR 4-73
4.13.5 DUPLEX EXIT SENSOR 4-73
4.13.6 DUPLEX/BY-PASS MOTOR 4-75
4.13.7 DUPLEX INVERTER MOTOR 4-76
4.14 BY-PASS 4-78
4.14.1 BY-PASS PAPER SIZE SENSOR 4-78
When reinstalling the by-pass paper size sensor 4-78
4.14.2 BY-PASS PAPER END SENSOR 4-79
4.14.3 BY-PASS PICK-UP, FEED AND SEPARATION ROLLER, TORQUE LIMITER 4-80
4.14.4 BY-PASS FEED CLUTCH 4-81
4.15 DRIVE AREA 4-82
4.15.1 PAPER FEED CLUTCH 4-82
Tray 1 and Tray 2 4-82
4.15.2 DEVELOPMENT PADDLE MOTOR 4-83
4.15.3 TRANSFER/DEVELOPMENT MOTOR 4-83
4.15.4 DRUM MOTOR 4-84
4.15.5 FUSING MOTOR 4-84
4.15.6 WEB MOTOR 4-85
4.15.7 PAPER FEED MOTOR 4-85
4.15.8 TRANSFER BELT CONTACT MOTOR 4-86
4.15.9 REGISTRATION MOTOR 4-86
4.15.10 TONER SUPPLY MOTOR 4-87
4.16 ELECTRICAL COMPONENTS 4-88
4.16.1 CONTROLLER UNIT 4-88
4.16.2 HDD UNIT (STANDARD FOR D011/D013/D091/D092) 4-88
Before replacing the HDD unit 4-88
Replacement Procedure 4-89
After installing the new HDD unit 4-89
4.16.3 CONTROLLER BOARD 4-90
Before replacing the controller board in the model without HDD 4-90
Replacement Procedure 4-90
When installing the new controller board 4-91
After installing the controller board 4-91

servicerepairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

4.16.4 MOTHER BOARD 4-92
4.16.5 BICU 4-93
4.16.6 IOB 4-93
When installing a new IOB 4-94
4.16.7 PSU 4-94
4.16.8 HIGH VOLTAGE POWER SUPPLY BOARD 4-95
4.16.9 FUSING EXHAUST FAN 4-95
When installing the fusing exhaust fan 4-96
4.16.10 CONTROLLER FAN 4-96
When installing the controller fan 4-96
4.17 COPY ADJUSTMENTS 4-97
4.17.1 OVERVIEW 4-97
4.17.2 PRINTING 4-97
Registration - Leading Edge/Side-to-Side 4-97
Blank Margin 4-99
Main Scan Magnification 4-100
Parallelogram Image Adjustment 4-100
4.17.3 SCANNING 4-101
Registration: Platen Mode 4-102
Magnification 4-102
4.17.4 ADF IMAGE ADJUSTMENT 4-103
Registration 4-103
4.17.5 TOUCH SCREEN CALIBRATION 4-104

service-repairmanuals.com

SERVICE TABLES

5. SERVICE TABLES 5-1
5.1 SERVICE PROGRAM MODE 5-1
5.1.1 SERVICE PROGRAM MODE OPERATION 5-1
Service Mode Lock/Unlock 5-2
5.1.2 SERVICE PROGRAM MODE TABLES 5-3
Service Table Key 5-3
5.2 SERVICE PROGRAM MODE TABLES 5-4
5.2.1 SP TABLES 5-4
5.3 USING SP MODES 5-5

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

5.3.1 TEST PATTERN PRINTING 5-5
5.3.2 SMC PRINT OUT LISTS: SP5-990 5-7
5.3.3 NIP BAND WIDTH ADJUSTMENT: SP1-109 5-8
5.3.4 MEMORY CLEAR: SP5-801 5-9
5.3.5 SOFTWARE RESET 5-11
5.3.6 SYSTEM SETTINGS AND COPY SETTING RESET 5-12
5.3.7 COPIER SETTING RESET 5-13
5.4 UPDATING THE FIRMWARE 5-14
5.4.1 BEFORE YOU BEGIN 5-14
5.4.2 UPDATING FIRMWARE 5-15
Preparation 5-15
Firmware Update Error 5-16
Recovery after Power Loss 5-17
5.4.3 HANDLING FIRMWARE UPDATE ERRORS 5-17
Error Message Table 5-17
5.5 NVRAM DATA UPLOAD/DOWNLOAD 5-19
5.5.1 UPLOADING NVRAM DATA (SP5-824) 5-19
5.5.2 DOWNLOADING NVRAM DATA (SP5-825) 5-19
5.6 SD CARD APPLI MOVE 5-20
5.6.1 OVERVIEW 5-20
Use caution when you do the SD Card Appli Move procedure: 5-20
5.6.2 MOVE EXEC 5-21
5.6.3 UNDO EXEC 5-22
5.7 SELF-DIAGNOSTIC MODE 5-23
5.7.1 SELF-DIAGNOSTIC MODE AT POWER ON 5-23
5.7.2 SELF-DIAGNOSTIC TEST FLOW 5-24
5.7.3 DETAILED SELF-DIAGNOSTIC MODE 5-25
5.7.4 EXECUTING DETAILED SELF-DIAGNOSIS 5-25
5.8 USING THE DEBUG LOG 5-26
5.8.1 OVERVIEW 5-26
5.8.2 SWITCHING ON AND SETTING UP SAVE DEBUG LOG 5-26
4-Digit Entries for Keys 1 to 10 5-29
Key to Acronyms 5-30
Retrieving the Debug Log from the HDD 5-31
Recording Errors Manually 5-31
5.9 DIP SWITCHES 5-32

service.copiadriver.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

service-repairmanual.com

5.9.1 I/O BOARD: DIP SW101 5-32

TROUBLESHOOTING

6. TROUBLESHOOTING 6-1
6.1 SERVICE CALL CONDITIONS 6-1
6.2 ELECTRICAL COMPONENT DEFECTS 6-2
6.2.1 SENSORS 6-2
6.2.2 SWITCHES 6-7
6.3 BLOWN FUSE CONDITIONS 6-8

ENERGY SAVING

7. ENERGY SAVING 7-1
7.1 ENERGY SAVE 7-1
7.1.1 ENERGY SAVER MODES 7-1
Timer Settings 7-1
Return to Stand-by Mode 7-2
Recommendation 7-2
7.1.2 ENERGY SAVE EFFECTIVENESS 7-3
7.2 PAPER SAVE 7-5
7.2.1 EFFECTIVENESS OF DUPLEX/COMBINE FUNCTION 7-5
1. Duplex: 7-5
2. Combine mode: 7-5
3. Duplex + Combine: 7-6

D009/D011/D012/D013/D091/D092

SERVICE MANUAL APPENDICES

SEE D009/D011/D012/D013/D091/D092 SERVICE MANUAL APPENDICES SECTION FOR DETAILED TABLE OF CONTENTS

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

B408 1000-SHEET FINISHER SR790

SEE SECTION B408 FOR DETAILED TABLE OF CONTENTS

B802 AUTO REVERSE DOCUMENT FEEDER DF3010

SEE SECTION B802 FOR DETAILED TABLE OF CONTENTS

B804/B805 BOOKLET FINISHER SR3020/FINISHER SR3030

SEE SECTION B804/B805 FOR DETAILED TABLE OF CONTENTS

B838 SCANNER ACCESSIBILITY OPTION TYPE 4045

SEE SECTION B838 FOR DETAILED TABLE OF CONTENTS

D346 FAX OPTION TYPE 5000

SEE SECTION D346 FOR DETAILED TABLE OF CONTENTS

D351 PAPER FEED UNIT PB3040

SEE SECTION D351 FOR DETAILED TABLE OF CONTENTS

D352 LCT PB3050

SEE SECTION D352 FOR DETAILED TABLE OF CONTENTS

D353 1200-SHEET LCIT RT3000

SEE SECTION D353 FOR DETAILED TABLE OF CONTENTS

D381 PRINTER/SCANNER OPTION TYPE 5000

SEE SECTION D381 FOR DETAILED TABLE OF CONTENTS

service-repairmanual.com

CÓPIA NÃO CONTROLADA

CÓPIA NÃO CONTROLADA

D386 BRIDGE UNIT BU3030

SEE SECTION D386 FOR DETAILED TABLE OF CONTENTS

D389 1-BIN TRAY BN3040

SEE SECTION D389 FOR DETAILED TABLE OF CONTENTS

service-repairmanual.com

CÓPIA NÃO CONTROLADA